



Room Stations with Call Cord Receptacles, Economy

HWN7669UC 2G Audio-Visual, Single Bed, 1 Call Cord Jack
 HWN7679UC 3G Audio-Visual, Dual Bed, 2 Call Cord Jacks

Description

The Economy Room Stations offer multiple call levels in a traditional option. Each wall-mounted device includes an answer LED indicator, a call LED indicator for each input receptacle, and a RESET button. The input receptacles accept one of the existing call cords: model HAN7608UA, HAN7609UA, or HAN7610UA. All models contain a bi-directional speaker/microphone for voice communications between patient and staff. An easy-to-clean, rugged, stainless steel faceplate provides lasting, professional style. Installation is straight forward and compatible with other patient stations used with the Call System. The various auxiliary call stations, such as the Pushbutton Emergency, Pull Cord Emergency, or Code Blue can be used in conjunction with the Economy series.



HWN7669UC

Features

- Fully programmable to address customer requirements including 4 input and 4 output channels
- Safety disconnect call cord places call when removed for emergency condition
- Service for one or multiple beds with one station
- Quick-disconnect terminals for simple installation and maintenance



HWN7679UC

Model Identification

HWN7669UC Economy room station with voice, 2-gang with phono jack receptacle, mounted on a stainless steel faceplate
 HWN7679UC Economy dual patient station with voice, 3-gang with two phono jack receptacles, mounted on a stainless steel faceplate

Technical Data

Input Power: 12 VDC, 1 mA DC standby current per station
 Output Power: 24 VDC, 250 mA DC max per output channel





Architect's Specifications

Model HWN7669UC shall be 2-gang, wall mounted devices with voice and include a brushed stainless steel faceplate. HWN7669UC shall have one phono jack receptacle for service of one or two beds, depending on the call cord selected. Model HWN7679UC shall be a 3-gang, wall mounted device with two phono jack receptacles for servicing two beds with individual readouts at the annunciator panel.

The front panel on each model shall include the following:

- One or two call cord receptacles, or Pushbutton switch
- One RESET button
- One station speaker/microphone
- One or two Call LED indicators

The phono-jack call cord receptacles shall accept any of the following call cord devices:

- Model HAN7608UA - single call cord
- Model HAN7609UA – dual call cord
- Model HAN7610UA - split function call cord

The station shall include a dip switch for selecting one of 32 unique polling addresses. It shall also include terminations for connection to auxiliary input devices, such as bath emergency, pushbutton emergency, staff locator, or code blue stations. It shall also provide output terminals for connection to dome light indicators. Quick-disconnect, insulation-displacement type connectors shall be provided to terminate field-installed power, control and audio lines.

Wall Box

Model HWN7669UC shall require a standard 2-gang X 3 1/2" masonry box, or equivalent.

Model HWN7679UC shall require a standard 3-gang X 3 1/2" masonry box, or equivalent.

