



“Staff” Console, Digital

Audio - HCN7636UA / Visual - HCN7638UA

Description

Two console models are available: The HCN7636UA for our Audio Systems and the HCN7638UA for Visual only systems. The Console is a compact, easy-to-use, desktop communications terminal for use with the 5000 series Call Systems. This attractive, contemporary-styled operator's console is equipped with a soft-touch keyboard and a large, 16-character LCD display, providing the integrated functionality needed to satisfy today's diverse nurse call requirements in hospitals, healthcare, senior housing and other commercial applications.



HCN7636UA

Features

- The easily read display indicates the location and priority code for the alarm
- Handset or Push-to-talk voice options
- Both tone and visual indicators alert the operator of incoming calls
- Built-in system diagnostics make operation and training easy
- Staff can increase productivity with the Remind, Priority and Nurse Follow functions
- Time-of-day display
- Easily programmable zone & system configuration

Technical Data Input Power: 12 VDC, 350 mA max



Architect's Specifications

Audio Staff Console – HCN7636UA

The Staff Console shall be a desk-top unit, model HCN7636UA. It shall contain a 24-key alpha-numeric, sealed keypad, including six back-lit keys, and a 16-character liquid crystal display (LCD) panel. Indicator lights shall include a POWER ON/OFF LED (GREEN) and a FAULT LED (YELLOW). The console shall include a telephone-type handset for two-way voice communications, with a provision for alternate push-to-talk operation. The Console shall be used to answer and place calls to patient and staff stations, monitor system status, change room map parameters, perform system diagnostics, etc. The Console shall include the necessary data, control and voice interface terminals to provide for field termination to the system Control Units. All wire terminations shall consist of pluggable connectors only.

Visual Staff Console – HCN7638UA

The Staff Console shall be a desk-top unit, model HCN7636UA. It shall contain a 24-key alpha-numeric, sealed keypad, including six back-lit keys, and a 16-character liquid crystal display (LCD) panel. Indicators shall include a POWER ON/OFF LED (GREEN) and a FAULT LED (YELLOW). The Console shall be used to identify calls from patient and staff stations, monitor the system status, activate selectable options, change room map parameters, perform system diagnostics, etc. The Console shall include the necessary data, control and interface terminals to provide for field termination to the system Control Units. All wire terminations shall consist of pluggable connectors only.

Rev11/05

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

