



CORNELL

Emergency Response Systems

A-1600 Remote Control



A-1612

CORNELL A-1600 panels offer convenient, reliable remote door control.

1-800-558-8957

Operation: Anodized aluminum A-1600 panels with integral LED indicators permit remote monitoring, arming and disarming of individual zones within the Series A-1000 Door Monitor System.

Indication: Steady green LEDs indicate unarmed status; steady red, armed status; flashing red with intermittent tone, an alarm condition. Zones are designated via plastic covered designation strips.

Controls: Tone volume is adjustable via high-low switch. Arm and disarm functions are operable via spring-return, center-off toggle switch.

Details: Anodized aluminum face plate, surface-, flush- or desktop-mountable.

Engineering Specifications

The contractor shall furnish and install CORNELL A-1600 Remote Control panels as indicated on the plans for use with the Series A-1000 Door Monitor System. Each (flush-) (surface-) (desktop) mountable panel shall accommodate __zone circuits. Indicators shall be LEDs; incandescent lamps are not acceptable. A steady green LED shall indicate unarmed status; steady red, armed status; flashing red with intermittent tone, an alarm condition. Tone volume shall be adjustable via high-low switch. Zones shall be designated with plastic-covered designation strips. Power shall be derived from the A-1000 master panel at 12 VDC, regulated. Each remote zone indication requires 17MA.

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

