

## *TR-S100E* Smoke Detector/Transmitter



### **TR-S100E Smoke Detector/Transmitter**

Our TR-S100E features GE Interlogix's latest smoke detector improvements including; longer battery life, CleanMe™ diagnostics, improved styling and more. Now powered by two Lithium batteries, battery life is estimated at up to five years. This reduces the inconvenience and cost of replacing batteries. The detector continually monitors itself, providing drift compensation and visual display of over- or under-sensitivity so that corrective action can be taken to reduce false alarms. The sophisticated electronics and replaceable optical chamber eliminates the need to send the smoke detector to the factory for recalibration. Includes batteries. UL approved for residential fire.

### **Engineering Specifications:**

Model: TR-S100E

Dimensions: 5.5" Diameter x 2.63"

Power: 3.0V Lithium

Battery Replacement: BAT604 (2 Required)

Battery Life: 3-5 years