

TR-U100IVE/TR-D100IVE Universal Transmitters



TR-U100IVE Reduced-Size Universal Transmitter

For use with any standard contact or sensor, this reduced-size universal transmitter comes with case tamper and supports an end-of-line resistor. Mounting bracket provided for quick and easy installation. Includes a 3.0V Lithium battery. UL Listed

TR-D100IVE Reduced-Size “Wide Gap” Door/Window Transmitter

Same as the TR-U100IVE, but includes two built in magnetic reed switches. It has one on top and one of the side for maximum flexibility. The reed switch can be used in tandem with the external switch. Includes magnet that supports a 5/8” gap and a 3.0V Lithium battery. UL Listed

Engineering Specifications:

Model: TR-U100IVE
Dimensions: 3.5” x 1.7” x 0.9”
Power: 3.0V Lithium
Battery Replacement: BAT604
Battery Life: 4-5 years

Model: TR-D100IVE
Dimensions: 3.5” x 1.7” x 0.9”
Power: 3.0V Lithium
Battery Replacement: BAT604
Battery Life: 4-5 years