



## Emergency Station with Momentary Switch E-144



E-144

**Description:** The Momentary Emergency Station (E-144) to be used with a latching Annunciator panel. The station features a satin finished stainless steel faceplate with silk screened designations.

**Operation:** Pulling the four-foot germ free, glow in the dark cord on the E-144 activates the momentary switch on the emergency station placing a call for help. Station is designed to be used with a latching Annunciator panel.

**Mounting:** The station may be flush mounted on a standard outlet box with single-gang plaster ring, or surface mounted on a Wiremold 5748.

**Engineering Specifications:** The contractor shall furnish and install the CORNELL E-144 Emergency Stations as indicated on the plans. Faceplates shall be satin-finish stainless steel with silk-screened designations.

### Technical Information:

- Power Requirements: 24VDC
- Operating Environment: 50-120°F Indoor Non-condensing
- Physical Faceplate Dimensions: 4 ½ "H x 2 ¾ "W (1 Gang)
- Mounting: Single-Gang back box with 1¾" minimum depth
- Wiring: Terminations are Pigtailed
- Now supplied with a plastic, anti-microbial, glow in the dark, 4 ft long pull cord



**Available in 1-6 gang sizes:**

\*stations are only UL Listed in the 1 gang size

\* For correct part number, change first number (1) to gang size needed

